

## PC Tyre sidewall marking



Tread tire pattern (Example : Pilot Preceda PP2)



Section width and aspect Ratio (Example : 245/35)      **R** = Radial tire      Rim diameter (Example : 19)      Load index & Speed index (Example : 93W)

## LT Tyre sidewall marking



Section width (Example : 205)      **R** = Radial tire      Tread tire pattern (Example : XCD)      Load index & Speed index (Example : 109/107P)      Rim diameter (Example : 14)      C=Camionette

## Radial Truck Tyre sidewall marking



Section width and aspect Ratio (Example : 295/80)      **R** = Radial tire      Tread tire pattern (Example: XZE2+)      Load index & Speed index (Example : 152/148M)      Rim diameter (Example : 22.5)